

Isytech programs



Touch button
**Special program
selection**

Touch button
**Standard program
selection**

Glasswasher

Washware / Category	Program	Standard	Special	Duration (sec.)	Wash (°C)	Rinse (°C)	44		45
							44-10D	44-11D 44-13D	45-13D
Glasses	Program for sturdy glasses	61	•	75	65	65	•	•	•
	Standard program	62	•	90	60	70	•	•	•
	Program for delicate glassware	63	•	100	60	65	•	•	•
Dishes / Plates	Intensive program	P3	•	150	55	85	•	•	•
Cups	Standard program	71	•	100	65	80	•	•	•
Self-cleaning	Drain	dr	•	varies	n.a	n.a		•	•
	Water exchange program	d1	•	varies	n.a	n.a		•	•
	Self-cleaning program	7L	•	300	cold	65		•	•

Dishwasher (Undercounter / Hood-type)

Washware / Category	Program	Standard	Special	Duration (sec.)	Wash (°C)	Rinse (°C)	46			48		
							46-10D 46-12D	46-11MD 46-11D 46-11SD	46-13D 46-13TD	48-10D 48-12D	48-11D	48-13D
Glasses	Standard program	62	•	90	60	70	•	•	•	•	•	•
Bottles	Main Wash + Rinse	62	•	80	60	60			•			•
	Rinse Only (Water Bottles)	61	•	40	n.a	45			•			•
Dishes / Plates	Short program	P1	•	75	60	70	•	•	•	•	•	•
	Standard program	P2	•	100	60	75	•	•	•	•	•	•
	Intensive program	P3	•	120	55	85	•	•	•	•	•	•
	Intensive long wash program	P5	•	600	60	80	•	•	•	•	•	•
Cups	Standard program	71	•	100	65	80	•	•	•	•	•	•
Self-cleaning	Drain	dr	•	varies	n.a	n.a		•	•		•	•
	Self-cleaning program	7L	•	300	cold	65		•	•		•	•